

## COMMENTS

This cartridge only has a part sponge. Refill the hole closest to the electronic strip. It is not necessary to reseal the holes. Tape over the vent holes if you plan to store the cartridge for a while to prevent the ink drying out.

## REQUIREMENTS

- 1 x 10 ml syringe and sharp needle.
- 5ml of appropriate black Ink for the HP92
- Head sealing tape and or cartridge clip.
- HSC1000 solution or steam for improved results.

## **REFILLING METHOD**

**Step 1.** Soak print head in HSC1000 for 10-20 mins or gently apply steam directly to printhead to remove dried ink from the print *b* ad assisted.

Step 2. Put the cartridge on some paper towels in an area where you can tolerate a spill.

Step 3. Peel off the top label.

Step 4. Fill the syringe with 5 ml. of appropriate black ink.

**Step 5.** Very S-L-O-W-L-Y inject ink into the chamber that is the near the electronic strip. Until 5 ml of ink has been inserted into the cartridge or the sponge is full. A little ink might come out of the top when full. If the cartridge is overfilled, draw some ink back with the syringe.

Step 6. When finished, replace the top label.

**Step 7.** Then do a DAB test.

Step 8. Replace the cartridge and run 1 - 3 cleaning cycles as per printer instructions.

© Ausjet Ink Jet Supplies and Service Pty Ltd