

Epson Refill Tool Instructions

Step 1)

Insert the cutter tool through the plastic label and turn the cutter so that it cuts the label away.



Step 2)

With a Stanley knife cut away any of the remaining plastic that is in the fill hole.



Step 3)

I) Insert the fitting at the end of the tube into the fill hole. This should be a tight fit.

II) Insert the end of a syringe into the cartridge outlet port. Push the syringe until it pushes down a valve and is quite firm in the cartridge.

III) Pull up on the syringe to remove the air from the cartridge. When non foaming is flowing into the syringe the ink cartridge is full.



Step 4)

Remove the fitting and insert the 5.3mm black rubber plug. (For peace of mind a small amount of silicon under the lip of the plug will guarantee the seal)

