





© Ausjet Ink Jet Supplies and Service Pty Ltd

COMMENTS

The 18C0034 is a high yield cartridge. Refill both cartridges with the same amount of ink. This will make them both high yield cartridges.

These are black, sponge filled cartridge. Sponge is brone to drying out which may cause it to accept less ink

REQUIREMENTS

- 18C0032 and 18C0034 15 ml Appropriate Black Pigment.
- 20 ml syringe with sharp needle
- Head sealing tape and or cartridge gip.

REFILLING METHOD

STEP 1.

Peel back the label on top of the cartridge enough to expose one of the holes on the top of the cartridge.

STEP 2.

Fill syringe with 15 ml ink and insert through the hole into sponge as far as it will go. Inject ink slowly into the cartridge making sure the needle is sitting on the bottom of the cartridge.

Cartridge may not accept all of the ink.

Sit cartridge on paper towel after filling to absorb any drips.

STEP 3.

.Use the Ausjet priming tool to remove air locks and prime the cartridge. Then do a DAB test. Then run 2 to 3 cleaning cycles and do a test print

STEP 4.

If not printing correctly gently steam or soak the printhead in hot water for 10–20 mins. Then repeat step3.