

Attach needle and filter to empty syringe and insert into cartridge through fill port hole. Insert the needle as close as possible to the small pin hole where the printer originally punctured the rubber dam. Remove syringe leaving needle and filter sticking out of the cartridge. The cartridge should be standing upright.

STEP 4.

Fill syringe with 50 ml of ink. Attach syringe to filter/needle assembly in cartridge and slowly inject the ink. Refill the syringe with a further 50 ml of ink and again inject into the cartridge. DO NOT INJECT AIR INTO CARTRIDGE. Now draw back on the syringe to remove any froth or air bubbles until clean ink shows in the sy-